



TTi Performance Exhaust and Headers  
Tube Technologies, Inc.  
Corona, California 92880-1726  
Phone (951) 371-4878

[www.ttiexhaust.com](http://www.ttiexhaust.com)

Sheet #306 / Footnote #70

## EXHAUST TIP / EXTENSION INSTALLATION

### Recommended Installation Procedure

1. TTi tips are designed to slip onto the tailpipe. Available in 2-1/2" or 3" I.D. (Inside Diameter)
2. You must decide just how far out from the valence or the bumper you would like your tips to protrude. Hold the tips into position and mark where to cut your tailpipe. A minimum of 2-1/2" straight tube must be maintained for proper clamping. Remove the burs from the cut and slide the tip into position.
3. Use the pre-drilled hole in the stainless tip as a drill guide. Drill through the tailpipe with a #30 drill bit. Insert the supplied rivet and place the stainless T-bolt clamp over the rivet and tighten the clamp.
4. The tip is now held firmly in position on the tailpipe and will never rotate out of alignment or slip off of the tailpipe.

